One Button STUDIO●+
OneButtonStudio.info

The One Button Studio+Plus is delivered 90% assembled; however, there are parts that need to be removed from the packaging, then assembled and/or mounted. Make sure you have everything on the list before beginning assembly. If something is missing, please email or call jason@dvestore.com, 855-687-8824.

Rolling Rack Cabinet

Dual Monitor Mount

2x 24" Monitors

Manfrotto Friction Arm

Camera w/ReflecMedia LiteRing

2x Studio Lights

Floor Button

2x Acoustic Panels

Integrated Control Console

Wireless Presenter Remote

Microphone w/Gooseneck & 25' XLR Cable

3x Drop Ceiling Scissor Clamp w/5/8" Stud

6x Drop Ceiling Scissor Clamp w/Cable Support

Cable Wrap

Cable Protector

14x Drywall Anchors

14x Steel Fender Washers

2x Tarp Clips

One Button STUDIO●+

OneButtonStudio.info

– Room Layout –

Chromatte Background (8'x8')

Acoustic Panel

Studio Light

Presenter

Directional Microphone

Foot Switch

Studio Light

Acoustic Panel

Cables on Ceiling

Cable on Floor

A/V Cart w/Camera & Reflecmedia LiteRing

10'-12' from camera to screen is ideal

One Button Studio+Plus Wiring Diagram

One Button STUDIO+
OneButtonStudio.info

- Studio Light
- Directional Microphone
- XLR
- Power
- POE Router
- SDI
- CAT 6
- Relay
- Relay
- Audio Mixer
- HD 15
- One Button
- 24" Monitor
- Camera
- Reflecmedia LiteRing
- One Button Studio Controller
- mimoLive
- Mac Mini i7
- BMD USMR
- Admin Keyboard
- USB
- NDI Screen Capture
- Keynote
- Mac Mini i3
- HDMI
- 24" Monitor
- Xkeys Control Panel
- User Keyboard
- Control Console
- USB
- USB
- Power
- Studio Light

Step 1: Monitor Mount & Monitors

Step 2: Camera Mounting & Cable Connections

One Button STUDIO+
OneButtonStudio.info
– Ceiling Hardware –

Acoustic Panel

Acoustic Panel

Cables on Ceiling

Cable on Floor

A/V Cart
w/Camera &
Reflecmedia
LiteRing

x6

x3

Studio
Light

Studio
Light

Directional
Microphone

Chromatte
Background
(8'x8')

Presenter

Foot
Switch

Step 5: Lights & Microphone

Step 6: Chromatte Curtain & Acoustic Panels

Video available here: https://onebuttonstudio.info/chromatte-curtain-installation/

One Button
STUDIO●+
OneButtonStudio.info

System Admin Info:

User Name: admin

Password: admin

Keyboard/Mouse Info:

This system runs software called ShareMouse, which allows a single keyboard and mouse to access both Macs. The mouse and keyboard on top of the cabinet is generally designated for use by the end-user, to access the Presentation Mac. However, it can be used by the admin to access the Recording Mac as well. Holding down the alt/option key when mousing to the edge of the screen, will allow the pointer to pass from one screen to the next. Generally, it should remain locked to the Presentation Mac screen, so the end-user does not have access to the Recording Mac. Inside the cabinet, there is a fallback keyboard and mouse connected to the Recording Mac.

Warranty:

The individual components that make up the One Button Studio+Plus system are all covered by their respective manufacturer's warranties, which are generally 12 months. If any component of the One Button Studio should fail during the first 12 months of ownership, DVEstore Inc. will facilitate repair or replacement of the faulty component, at no charge.

If any component of the One Button Studio should fail after the first 12 months of ownership, DVEstore Inc. will facilitate repair or replacement of the faulty component, charging the retail price of the repair or replacement.

Support:

Technical support is provided by the One Button Studio+Plus developer, Jason Jenkins. He is available via phone: 855-687-8824 or email: jason@dvestore.com to assist with any problems.

Support content is also available at https://onebuttonstudio.info/support, including video tutorials, images and documents.

Network setup: https://onebuttonstudio.info/network-settings/

USB thumb drive information: https://onebuttonstudio.info/thumb-drive-recommendations-for-the-one-button-studio/

Setting camera zoom & focus presets: https://onebuttonstudio.info/updating-camera-zoom-and-focus-presets/

Changing backgrounds & watermarks: https://onebuttonstudio.info/changing-the-chroma-key-background-logo-options/